



NAGRYWARKA ZEWNĘTRZNA DVD/CD

INSTRUKCJA

PL



DIODA STATUSU
PRZYCIŚK DO OTWIERANIA
OTWÓR DO AWARYJNEGO OTWIERANIA

Napęd należy podłączyć dołączonym do zestawu kablem USB do kompatybilnego urządzenia. Po podłączeniu w zależności od ustawień komputer poinformuje użytkownika o gotowości urządzenia do pracy. Proces rozpoznawania urządzenia przez komputer powinien trwać krócej niż minutę.

Aby otworzyć kieszeń na dysk automatycznie. Wejdź w „Mój Komputer”, kliknij prawym przyciskiem myszy na napęd, a następnie lewym przyciskiem myszy na słowo „Wysuń”

Wiązka lasera z napędu jest szkodliwa, nie należy patrzeć w nią bezpośrednio, ani oślepiać nią innych osób.

Nie użytkować w pobliżu silnych źródeł pola magnetycznego.

Urządzenie powinno być umieszczone na stabilnej podstawie.

Urządzenia nie można dotykać, ani przemieszczać podczas pracy.

SPECYFIKACJA TECHNICZNA:

WYMIARY: 142x142x19 mm

POBÓR MOCY: 3-5 W

WSPIERANE FORMATY: DVD-ROM, DVD-R, DVD+R, DVD-RW, DVD-R DL, CDA, CD-ROM, CD-R, VCD, SVCD, CD-RW
KOMPATYBILNY Z SYSTEMAMI OPERACYJNYMI: WINDOWS XP, 2003, VISTA, 7, 8, 8.1, 10, 11; LINUX; MAC OS 10 I NOWSZYMI
PRZEWÓD: WYKONANY Z CZYSTEJ MIEDZI, W GUMOWYM OPLOCIE. PRZECIWDZIAŁA ZAKŁÓCENIOM, NIE TŁUMI SYGNAŁU. KOMPATYBILNY ZE STANDARDEM USB, ZŁĄCZE USB TYP A. W PRZYPADKU STARSZYCH ZŁĄCZ, NAPĘD MOŻE WOLNIEJ ODCZYTYWAĆ / ZAPISYWAĆ DANE.

ODDATKOWE OPROGRAMOWANIE: NIE JEST POTRZEBNE, URZĄDZENIE DZIAŁA OD RAZU PO PODŁĄCZENIU [PLUG & PLAY].

Użytkowanie i wyłączenia gwarancyjne:

- Produkt powinien być używany zgodnie z jego przeznaczeniem, niewłaściwe jego użytkowanie może spowodować uszkodzenie produktu oraz zagrożenie dla zdrowia użytkownika;
- Nadmierna wilgoć, kurz oraz inne zanieczyszczenia mogą spowodować uszkodzenia produktu, które nie są objęte gwarancją;
- Gwarancja nie obejmuje uszkodzeń mechanicznych produktu;
- Należy unikać ekspozycji na radykalne zmiany temperatury otoczenia, w przypadku ich wystąpienia przed użyciem produktu należy zaczekać ok. 30 minut na wyrównanie temperatury;
- Szczegółowe warunki gwarancji są dostępne na stronie <https://krux.tech/>.

ENTITY RESPONSIBLE/
PODMIOT ODPOWIEDZIALNY:
COOLING.PL ZDZIECH SP.J
UL. SOKOŁOWSKA 24
05-806 SOKOŁÓW, POLAND
TEL. +48 22 292 01 30
BDD: 000020025

KRX0123
WWW.KRUX.TECH



X EXTERNAL KRUX DVD/CD WRITER



INDICATOR LIGHT
EJECTION BUTTON
FORCED EJECTION HOLE

Products through standard USB data cable to the computer USB port properly connected, the computer monitor should appear in the lower-right corner of the icon. Click "My Computer" on the desktop should be displayed in the removable storage devices.

Click on this icon, right-click and select "eject" in the tray into the disc to read.

Internal laser light source may be harmful to the eyes of the face, Please do not look directly.

Do not have the machine on a strong magnetic objects nearby.

Keep the machine steady on the desktop, do not put it unstable items.

Don't put the machines on the vulnerable to squeeze place, to ensure normal machine use.

KRX0123
WWW.KRUX.TECH

ENTITY RESPONSIBLE/
PODMIOT ODPOWIEDZIALNY:
COOLING.PL ZDZIECH SP.J.
UL. SOKOŁOWSKA 24
05-806 SOKOŁÓW, POLAND
TEL. +48 22 292 01 30
BDD: 000020025

EN

USER'S GUIDE

TECHNICAL SPECIFICATION:

SIZE: 142x142x19 mm

POWER CONSUMPTION: 3-5 W

SUPPORT FORMAT: DVD-ROM, DVD-R, DVD+R, DVD-RW, DVD-R DL, CDA, CD-ROM, CD-R, VCD, SVCD, CD-RW
COMPATIBLE SYSTEM: WINDOWS XP, 2003, VISTA, 7, 8, 8.1, 10, 11; LINUX; MAC OS 10 OR NEWER.

CABLE: DATA CABLE PURE COPPER BRAID PROCESS, ANTI-INTERFERENCE ABILITY, SIGNAL ATTENUATION, MORE STABLE DATA TRANSMISSION.

COMPATIBLE WITH USB STANDARD, USB TYPE A PLUG. FOR AN OLDER DEVICES READING / WRITING SPEED MAY BE WORSE.

SOFTWARE: NO EXTRA DRIVE, SUPPORT PLUG AND PLAY.

Use and warranty limitations:

- The product should be used according to it's intended purpose. Incorrect use can damage the product and endanger the life of the user;
- Excessive humidity, dust and other contaminations can result in product damage which is not covered by the warranty;
- Avoid exposure to rapid changes ambient temperature. Should they occur, wait approx. 30 minutes before using the product until temperature is leveled;
- You can find the warranty terms and conditions at <https://krux.tech/>.

